

```

0000000JJJJJ #SSSS000000 01 0000 MMDDYY 2400 MMDDYY 0060 06 L 100 ROW 102
0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 02000000 'FHWA-USA
COUNTY CITY LOCATION
02 15 0001 0002 0003 0004 0005 0006 0007 0008 0009 0010 0011 0012 0013 0014 0015
01 02 0001 0002
00 00
01 01 0 0100 0000 0012 0007 0000 0000 0000 0000 0000 0001 0000 0000 0000 0000 0000
01 02 2 0100 0000 0018 0006 0000 0001 0000 0000 0000 0000 0000 0000 0000 0000 0000
01 01 0 0200 0000 0008 0003 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
01 02 2 0200 0000 0010 0002 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
01 01 0 0300 0000 0010 0004 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
01 02 2 0300 0000 0008 0003 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
01 01 0 0400 0000 0008
01 02 2 0400 0000 0008
01 01 0 0500 0000 0031
01 02 2 0500 0000 0052
01 01 0 0600 0000 0118
01 02 2 0600 0000 0118
01 01 0 0700 0000 0238
01 02 2 0700 0000 0197
01 01 0 0800 0000 0241
01 02 2 0800 0006 0205
01 01 0 0900 0001 0252
01 02 2 0900 0005 0178
01 01 0 1000 0000 0143
01 02 2 1000 0000 0154
01 01 0 1100 0000 0130
01 02 2 1100 0000 0138
01 01 0 1200 0001 0145
01 02 2 1200 0000 0142
01 01 0 1300 0000 0168
01 02 2 1300 0000 0136
01 01 0 1400 0000 0186
01 02 2 1400 0000 0146
01 01 0 1500 0000 0224
01 02 2 1500 0000 0191
01 01 0 1600 0000 0285
01 02 2 1600 0000 0269
01 01 0 1700 0001 0347
01 02 2 1700 0001 0257
01 01 0 1800 0000 0323
01 02 2 1800 0000 0333
01 01 0 1900 0000 0267
01 02 2 1900 0000 0214
01 01 0 2000 0000 0178
01 02 2 2000 0000 0182 0030 0000 0002 0000 0001 0005 0001 0000 0000 0000 0001 0000 0000
01 01 0 2100 0000 0151 0019 0000 0000 0001 0000 0000 0000 0000 0000 0000 0000 0000 0000
01 02 2 2100 0000 0160 0020 0000 0000 0000 0002 0003 0000 0000 0000 0000 0000 0000 0000
01 01 0 2200 0000 0128 0015 0000 0002 0000 0000 0000 0001 0000 0000 0000 0000 0000 0000
01 02 2 2200 0000 0113 0017 0000 0000 0001 0000 0000 0001 0001 0000 0000 0000 0000 0000
01 01 0 2300 0000 0047 0003 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
01 02 2 2300 0000 0050 0007 0000 0001 0000 0000 0000 0001 0000 0000 0000 0000 0000 0000
01 01 0 2400 0000 0023 0007 0000 0000 0000 0000 0000 0000 0001 0000 0000 0000 0000 0000
01 02 2 2400 0000 0024 0008 0000 0001 0000 0000 0000 0000 0001 0000 0000 0000 0000 0000
01 01 0 0100 0000 0012 0000 0000 0001 0000 0000 0000 0000 0000 0000 0000 0000 0000
01 02 2 0100 0000 0018 0003 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
01 01 0 0200 0000 0004 0001 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000

```

First Row:
0000000JJJJJ = Job Number (12 digits total)
#SSSS0000000 = Station Number (12 digits total)
= 2 for Program, 3 for Special
0000 = Start Time (4 digits total)
MMDDYY = Start Date (6 digits total)
2400 = End Time (4 digits total)
MMDDYY = End Date (6 digits total)
0060 = Main Interval (4 digits total)
L = Total Number of Lanes
ROW = Total Number of Rows preceded by 4 spaces

Second Row:
Nine Sets of 0000
02000000 = Direction by Lane (8 digits total)
example: 00220000 = 4 lanes (00=NB, 22=SB)

Fourth Row:
02 = Count Type (1=Volume, 2=Classified)
15 = Number of Bins
0001 = Bin #1

Fifth Row:
01 = Lanes starting from
02 = Total Number of Lanes
0001 0002... = Lane 1, Lane 2

Seventh Row:
01 = Default value
01 = Lane Number
0 = Lane Direction (N=0, E=1, S=2, W=3)
0100 = First Interval (Hour)